

Installation instructions

Transportation | Installation | Operation | Maintenance | Disposal



Dual COMPACT

Series: GADC CX



*This manual is to be considered part of the unit.
Read and follow this manual carefully before performing any work on the unit.
Always keep this manual accessible in the immediate vicinity of the unit
for future reference.*

guntner.com/us

About us

Product family and line:	Dual COMPACT
Version number:	1
Date of revision:	April 28, 2026

Copyright © 2026 by Guntner U.S. LLC

This publication is protected by copyright.

All rights reserved. No part of this documentation may be copied, reproduced or transmitted into a form suitable for electronic systems and distributed in any form, even in part, without the authorisation of Guntner U.S. LLC.

Should you require further assistance, please do not hesitate to get in touch with us:

© Guntner U.S. LLC

3601 Algonquin Road Suite #925

Rolling Meadows, Illinois 60008

United States of America

Online support: <https://guntner.com/en-us/contact>

To obtain the full TERMS & CONDITIONS OF SALE AND DELIVERY policy please consult the following link:

<https://guntner.com/en-us/info/legal-notice>

Contents

1	Key basic information.....	7
1.1	Importance of the instructions.....	7
1.2	Applicable documents.....	7
1.3	Responsibilities.....	7
1.3.1	Responsibilities of the installing contractor.....	7
1.3.2	Responsibilities of the owner.....	8
1.4	Definition of the target group and requirements.....	8
1.5	Legal note.....	11
1.6	Document conventions.....	12
1.7	List of abbreviations.....	12
1.8	Conventions for safety signs and instructions.....	13
1.8.1	General safety signs and their meaning in these instructions.....	13
1.8.2	Warning signs and their meaning in these instructions.....	13
1.8.3	Prohibitory signs and their meaning in these instructions.....	15
1.8.4	Mandatory signs and their meaning in these instructions.....	15
2	Description.....	16
2.1	Types of Dual COMPACT.....	16
2.1.1	Technical data of the unit.....	18
2.1.2	Technical data of the fans.....	18
2.2	General information.....	18
2.3	Design and function.....	19
2.3.1	Versions.....	19
2.3.2	Operating modes.....	21
2.4	Fan motor.....	22
3	Safety.....	23
3.1	Intended/improper use.....	23
3.1.1	Intended use.....	23
3.1.2	Operating conditions.....	23
3.1.3	Improper use.....	23
3.2	Labelling on the packaging/the unit.....	24
3.2.1	Packaging overview.....	24
3.2.2	Signs and notes on the packaging.....	25
3.2.3	Unit overview.....	25
3.2.4	Signs and notes on the unit.....	26

3.3	Basic safety instructions.....	27
3.3.1	Please note.....	27
3.3.2	Electrical hazard.....	28
3.3.3	Hazard due to working fluids.....	28
3.3.4	Hazard due to vibrations.....	30
3.3.5	Hazard due to pressurized parts.....	31
3.3.6	Thermal hazard.....	31
3.3.7	Mechanical hazard.....	32
3.3.8	Hazard due to fans.....	33
3.3.9	Other hazards.....	34
4	Transportation and unpacking.....	35
4.1	Safety instructions for transportation and unpacking.....	35
4.2	Transportation and storage of the unit.....	37
4.2.1	Transportation of the unit.....	37
4.2.2	Storing the unit prior to installation.....	38
4.3	Unpacking the unit.....	39
4.4	Checking the transportation pressure.....	40
5	Installation and commissioning.....	43
5.1	Safety instructions for installation and commissioning.....	43
5.2	Requirements for the place of installation.....	44
5.3	Installation of the unit.....	47
5.3.1	Installing the unit.....	47
5.4	Connecting the unit.....	49
5.4.1	Connecting the unit to the plant.....	49
5.4.2	Connecting the drain line to the tray.....	51
5.5	Electrically connecting and protecting the unit.....	53
5.6	Connection diagrams.....	54
5.7	Performing an acceptance test.....	54
6	Operation.....	57
6.1	Safety instructions for operation.....	57
6.2	Putting the unit into operation.....	57
6.3	Taking the unit out of operation.....	58
6.4	Shutting down the unit.....	59
6.5	Putting the unit back into operation after shutdown.....	60
6.6	Defrosting.....	60
6.6.1	Defrosting functions.....	60
6.6.2	Defrosting the unit.....	62

6.6.3	Factors influencing the defrosting process.....	64
6.6.4	Defrost control.....	64
6.7	Changeover to a different working fluid.....	65
6.8	Troubleshooting.....	66
7	Maintenance and cleaning.....	68
7.1	Safety instructions for maintenance and cleaning.....	68
7.2	Procedure prior to all maintenance work.....	70
7.3	Inspection/maintenance schedule.....	70
7.3.1	Unit.....	70
7.3.2	Heat exchanger coil.....	71
7.3.3	Fans.....	72
7.4	Maintenance work.....	73
7.4.1	Fixing leaks.....	73
7.4.2	Cleaning the unit.....	73
7.4.3	Remove/hinge down the tray and side cover.....	74
7.4.4	Cleaning the coil.....	74
7.4.5	Cleaning the fans.....	76
7.5	Procedure after all maintenance work.....	77
8	Dismantling and disposal.....	78
8.1	Safety instructions on dismantling and disposal.....	78
8.2	Dismantling the unit.....	79
8.3	Disposing of the unit.....	79
9	Spare parts.....	81
10	Accessories.....	82
10.1	Accessories available as a standard.....	82
10.2	Streamer.....	82

Version history

The following table lists the respective changes compared to the old versions.

Attention! Minor changes to the instructions, such as the wording of the text or the layout, are not listed separately.

Version of the instructions	Changes/additions
1	Version of the instructions after which the version history was introduced

1 Key basic information

1.1 Importance of the instructions

These instructions apply for the units of the Dual COMPACT product family and line. The Güntner Air Dual COMPACT (GADC CX) is a dual discharge unit for heat extraction for indoor installation with variable equipment for many applications of Commercial Refrigeration. The Güntner Air Dual COMPACT (GADC CX) is designed for operation with CO₂ as the working fluid, based on the evaporator operating principle, and is available with a variety of casings and adapted fan concepts.

Legal framework

These instructions have been written for the US Market. Design Product Safety Signs and Labels on the machine in accordance with ANSI Z535.

1.2 Applicable documents

The following documents are applicable:

- These instructions
- Documentation on selected accessories, if any
- Connection diagram (enclosed with the terminal box)
- For further technical data, see nameplate

These instructions are part of the system's operating instructions, which are provided by the system's manufacturer.

1.3 Responsibilities

1.3.1 Responsibilities of the installing contractor

The installing contractor is responsible for ensuring that this system is designed and installed in accordance with the local applicable codes, standards and safety regulations.

The installing contractor has the following obligations:

- Planning, design and calculation of the system in acc. with the statutory provisions, possibly also by an external planning consultancy (for required qualifications, see "Definition of the target group and requirements").
- Planning and preparing emergency measures:
 - To prevent consequential damage caused by malfunction, a warning system that immediately signals all faults must be provided on site.
 - Prepare emergency measures that prevent consequential damage to persons, property and the environment should faults occur.

- Specify inspection and maintenance intervals:
 - The system must be designed and equipped with all required equipment for maintenance, servicing and testing in acc. with the local applicable codes, standards and safety regulations.
- Point out the need for sufficient instruction of the operating and monitoring personnel for the operation and maintenance of the system.
- Inform Güntner U.S. LLC immediately if faults occur during unpacking, installation, start-up and operation.

1.3.2 Responsibilities of the owner

The owner must ensure that the employees entrusted with the operation, monitoring and maintenance of the system are adequately instructed and competent (see section "Definition of the target group and requirements", page 8).

Before commissioning the system, the owner must ensure that the operating personnel are sufficiently instructed about the system's documentation on the setup, monitoring, operating principles and maintenance of the system, as well as the safety measures to be observed and the properties and handling of the working fluid to be used.

The owner must ensure that, when operating, monitoring and maintaining the system, the working fluid and unit type do not deviate from the information specified in the order documents.

Planning and preparing emergency measures: To prevent consequential damage caused by malfunction, a warning system that immediately signals all faults must be provided on site. Prepare emergency measures that prevent consequential damage to persons, property and the environment should faults occur.

Responsibility remains with the owner of the system if the system is used by anybody else, unless there is an agreement on a different division of responsibilities.

1.4 Definition of the target group and requirements

General

Only persons who meet the requirements for the personnel may work in the area of the unit. This group of persons is defined below. To prevent damage to health and property, the owner must take measures to prevent unauthorized persons from gaining access to the unit.

Persons responsible for working on this unit in the various phases of its life cycle must have the necessary qualifications and competence for the respective tasks in acc. with the applicable local regulations.

Definition of the group of persons

Person	Qualification
Truck driver	Valid Class A CDL, additional training for heavy/permit loads if applicable
Crane/forklift operator	Valid driving and operator's license for crane/forklift truck

Person	Qualification
Warehouse worker	Specialized training as a warehouse worker or at least sufficient in-house qualification
Suitably qualified electrician	Certified training to become a qualified electrician
Pipefitter/welder	Certified training for the installation and welding of pipes and installation of heat exchangers and refrigeration piping
Refrigeration technician	A refrigeration technician should have comprehensive technical knowledge. This includes an understanding of how refrigeration systems work, the ability to install and repair equipment, knowledge of safety practices and the ability to read technical drawings and blueprints.
Mechanic	Training to become an industrial mechanic or comparable specialized training
Operator	Suitably qualified to monitor the safe operation of the system
Cleaning professional	Instruction in the use of cleaning methods and suitable cleaning agents
Installing contractor	Can be a person or a company that is responsible for the engineering and assembly and installation of the entire cooling system in the name of the owner and has a staff of trained engineers and technicians (see qualifications above)
Owner	The owner of the equipment can be a person or a company, who has the legal right to the machinery and to whom it belongs

Definition of tasks for the respective life cycle phases

Life cycle phase	Task	Group of persons
Transportation and storage	Transportation of the unit to the storage location or the place of installation	Truck driver
	Loading/unloading	Crane operator, warehouse worker
	Performing incoming goods inspection	Warehouse worker
	Performing intermediate storage	Crane operator, warehouse worker
Unpacking	Unpacking	Mechanic, warehouse worker
	Checking the holding pressure	Pipefitter/welder, refrigeration technician
	Performing maintenance runs of fans	Suitably qualified electrician
	Disposing of packaging material	Warehouse worker
Mounting/installation	Loading/unloading at the place of installation	Crane operator
	Mounting/installing and removing	Pipefitter/welder, refrigeration technician, mechanic
Connection	Connecting electrical components	Suitably qualified electrician
	Connecting hydraulic/refrigeration components	Pipefitter/welder, refrigeration technician
	Flushing the pipes	Pipefitter/welder, refrigeration technician
	Initial start-up (performing acceptance tests)	Refrigeration technician
Commissioning	Filling with working fluid	Pipefitter/welder, refrigeration technician
	Performing the commissioning and settings	Refrigeration technician
Operation	Performing functional checks	Operator
	Switching on/off	Operator
	Monitoring the cooling operation	Pipefitter/welder, refrigeration technician, operator
	Checking for damage	Skilled electrician, pipefitter/welder, refrigeration technician, operator
Troubleshooting	Performing a visual inspection	Skilled electrician, fitter/welder, mechanic, operator, cleaning professional
	Performing refrigeration tests	Refrigeration technician
	Performing electrical tests	Suitably qualified electrician, refrigeration technician

Life cycle phase	Task	Group of persons
Maintenance/repair	Performing a visual inspection	Operator
	Replacing wear parts	Suitably qualified electrician, pipefitter/welder, refrigeration technician, mechanic
	Performing weekly maintenance	Operator
	Performing annual maintenance	Suitably qualified electrician, pipefitter/welder, refrigeration technician, mechanic
	Replacing fans	Suitably qualified electrician, refrigeration technician, mechanic
	Replacing the control system	Suitably qualified electrician, refrigeration technician
	Fixing leaks	Pipefitter/welder, refrigeration technician
	Performing cleaning tasks	Pipefitter/welder, refrigeration technician, cleaning professional
Shutdown and taking out of operation	Shutting down	Pipefitter/welder, refrigeration technician
	Taking out of operation	Pipefitter/welder, refrigeration technician
	Draining propylene glycol	Refrigeration technician
	Draining (water)	Pipefitter/welder
Removal	Disconnecting the lines	Suitably qualified electrician, refrigeration technician
	Disassembling/dismantling/removing	Pipefitter/welder, refrigeration technician, mechanic
Disposal	Disposing of materials	Crane/forklift operator and truck driver, refrigeration technician, operator

1.5 Legal note

Please note that any warranty and/or liability claims require the presence of a proven defect of the unit supplied by us.

These installation instructions are an integral part of the supplied unit. It is essential that the contents of these installation instructions are fully observed. Any damage and/or malfunction resulting from failure to observe the contents of these installation instructions will not be covered by our warranty/liability. This applies in particular, but not exclusively, to the use of spare parts other than those specified (in case of doubt: use only original Güntner spare parts) and to unauthorized modifications to the unit compared to its original delivery condition, i.e. modifications without the express written consent of Güntner U.S. LLC. In particular, but not exclusively, modifications requiring our prior approval include the use of working fluids other than those specified, changes to the operating parameters and mechanical changes such as machining (e.g. drilling) without adequate protection of the unit from the resulting metal chips.

1.6 Document conventions

Mark-up elements for special information

bold	Requires special attention!
⇒ –	Instructions Instructions (sub-item)
• ◦	Listing Listing (sub-item)

1.7 List of abbreviations

General list of abbreviations

Abbreviation	Meaning
A, Amps	Ampere (electrical current)
ANSI	American National Standards Institute
ASHRAE	American Society of Heating, Refrigeration and Air conditioning Engineers
EEV	Electronic Expansion Valve
Hz	Hertz (frequency)
Emergency STOP	Switch for immediately switching off the refrigeration system
TXV	Thermostatic Expansion Valve
V	Volt (electrical voltage)
Ø	Diameter
1~	Single-phase alternating current
3~	Three-phase current

List of abbreviations in metric system

Abbreviation	Meaning
°C	Celsius degrees (temperature unit)
l	Liter (volume)
mm	Millimeter (length)
kg	Kilogram (weight)
bar	Bar (pressure)

List of abbreviations in imperial system

Abbreviation	Meaning
°F	Fahrenheit degrees (temperature unit)
gal	Gallons (volume)
in	Inch (length)
lb	Pound (weight)
psi	Pounds per square inch (pressure indication)

1.8 Conventions for safety signs and instructions

1.8.1 General safety signs and their meaning in these instructions

⚠ DANGER
Addresses a hazardous situation which, if encountered, will result in death or serious injury.
⚠ WARNING
Addresses a hazardous situation which, if encountered, might result in death or serious injury.
⚠ CAUTION
Addresses a hazardous situation which, if encountered, could result in minor or moderate injury.
NOTICE
Indicates instructions that pertain to safe equipment operation. Failure to comply with these instructions could result in damage to the equipment.
SAFETY INSTRUCTIONS
Indicates specific safety-related instructions or procedures.

1.8.2 Warning signs and their meaning in these instructions



Warning of hand injury

Failure to observe the warnings can result in hands or fingers being crushed, drawn in or otherwise injured.



Warning of hot surface

The temperature is above +113 °F (+45 °C) (the temperature at which protein clots) and can cause burns.



Warning of extreme cold
The temperature is below +32 °F (0 °C) and can cause frostbite.



Warning of dangerous electrical voltage
Risk of an electric shock if live parts are touched.



Warning of heavy loads
Severe injuries can occur when lifting.



Warning of the risk of cutting
Sharp edges and corners.



Warning of risk of crushing
Transportation, loading and unloading can result in life-threatening injury.



Warning of the risk of slipping
After defrosting, after cleaning work or due to other circumstances, there is a risk of slipping.



Warning of explosive substances at the place of installation
Use of ignition sources can cause explosions at the place of installation.



Warning of flammable substances at the place of installation
Use of ignition sources can cause fire at the place of installation.



Warning of toxic substances at the place of installation
Contact with or inhaling toxic substances can cause injury or death.



Warning of suspended loads
Standing under suspended loads can cause injury or death.



Warning of risk of suffocation
Being in an atmosphere with oxygen deficiency or with hazardous substances, gases or vapours can cause suffocation and death.



Warning of falling objects
Standing under falling objects can cause injury or death.



Warning of swivelling parts of the unit
Standing within the swivel range of the unit can cause injury or death.



Warning of high operating pressure
Breakage of pressurised components can cause injury or death.



Warning about general risks
General hazards to persons can cause injury or death.



Warning of automatic start-up
Automatic start-up of fans can result in hands and fingers being trapped.



Warning of the danger of pulling in
If body parts are being pulled into the unit, this can cause injury or death.

1.8.3 Prohibitory signs and their meaning in these instructions



No fire, no naked flames and no smoking!

Ignition sources must be kept away or at a safe distance, and ignition sources must not develop.

1.8.4 Mandatory signs and their meaning in these instructions



Use hearing protection!

Hearing protection must protect against loud noises.



Wear protective clothing!

Personal protective clothing must be suitable for the working fluid used and for low temperatures respectively, and must have good heat insulation properties.



Completely disconnect before working!

Completely disconnect the electrical system and secure it against restart before performing installation, maintenance and repair work.



Use eye protection!

Eye protection must protect against mechanical and chemical dangers and radiation.



Wear protective headgear!

Head protection must protect against hazards caused by impact with objects, swinging objects, falling objects or ejected objects.



Wear safety shoes!

Safety shoes must protect against external, damaging influences and offer protection against slipping.



Wear protective gloves!

Protective gloves must protect against mechanical and chemical dangers.



Observe manual!

Read the manual carefully and follow its instructions.



Use respiratory protection!

Breathing apparatuses must be suitable for the working fluid used. Breathing apparatuses must consist of:

- At least two self-contained breathing apparatuses (respiratory protective devices)
- For ammonia: an additional breathing apparatus with filter (full mask) or a self-contained breathing apparatus (respiratory protective device)

2 Description

2.1 Types of Dual COMPACT

Introduction

Güntner's Dual COMPACT GADC is a unit with variable equipment. Depending on the requirements, it can be configured in the most diverse variants. The following tables show the individual configuration options available for Güntner units.

Refer to the order documents for the exact unit name.

Letter (example)	Meaning	Possible variants
G	Company	G: G üntner
A	Function	A: A ir cooler (air cooler/evaporator)
D	Design	C: C ubic S: S lim D: D ual M: M ini I: I nsulated F: F loor
C	Product line	C: C OMPACT V: V ARIO P: P rocess [APPLICATION] A: A gri [APPLICATION] B: B last [APPLICATION]
C	Fluid	A: A mmonia R: R efrigerants (A1 refrigerants) C: C O ₂ P: P otentially dangerous (refrigerants of class A2L and higher) F: F luids in general W: W ater (water operation only)
X	Operating mode	P: P ump X: Direct eX pansion G: G ravity

Exemplary presentation of the nomenclature

SAFETY INSTRUCTIONS

If not marked separately, all information in the following sections refer to the standard unit!

Fans

Number of fans	Fan diameters
2 - 5	12-3/8 in (315 mm)

Available working fluids and their operating modes

Working fluid	Operating mode
Carbon dioxide (CO ₂)	DX (direct expansion)

Available defrost types

	Circulating air	Electric	Hot Gas
Coil and tray	X	X	X

Material combinations available as a standard

Material	Core tube	Fin	Casing	Tray
AlMg			X	X
Aluminium		X		
Copper	X			
Stainless steel	X			

X Standard design

Accessories available as a standard

- Electric defrost heater
- Hot gas defrosting
- Air streamer
- Cover coatings
- TXV and EEV
- Pressure transducer
- Temperature sensor
- Check valves for hot gas
- Solenoid valves
- Repair switch

2.1.1 Technical data of the unit

See nameplate

2.1.2 Technical data of the fans

Safety

SAFETY INSTRUCTIONS

The capacity values of the fans depend on the ambient temperature and the air resistance at the place of installation.

All electrical parts are designed in acc. with ASHRAE standards.

The technical delivery conditions are in acc. with ASHRAE standards.

Degree of protection	At least IP54 in acc. with ASHRAE standards
Type of current	Alternating current
Voltage	1~ 230 V, 50/60 Hz
Permissible ambient temperature	-40°F to +104 °F (-40°C to +40 °C)


2.2 General information

Introduction

Units of the Dual COMPACT product family are intended for installation in a refrigerating plant. The refrigerating plant is a combination of interconnected refrigerant-carrying components and fittings that form a closed circuit in which the working fluid circulates.

Overview

The design and function are shown using the standard unit of the Dual COMPACT GADC family.



Function


No.	Designation	Function
1	Fan	Sucks the ambient air into the casing. The air flows into the room again via the heat exchanger
2	Fins	Take up the heat of the working fluid from the ambient air
3	Fixing points	For fixing the unit to the ceiling
4	Removable side panel (on both sides)	Access to the connections, fittings and terminal box
5	Tray with condensate drain can be hinged down on both sides	Holds the fans; is insulated in such a way that no drops form under the cooler. The condensate drain drains the condensate and the condensation water. If the unit is designed with the optional condensate pump, there is no condensate drain.

2.3 Design and function


2.3.1 Versions

Overview

The unit is available with up to four fans in the following versions:



Enlarged images to show detail for table reference:



Refer to the following tables for the dimensions for the units available sizes.

Air and electrical defrost dimensions						
# Fans	Height (H)		Width (F)		Length (L)	
	mm	in	mm	in	mm	in
2	337	13-1/4	795 +/-5	31-5/16	1334	52-1/2
3	337	13-1/4	795 +/-5	31-5/16	1810	71-1/4
4	337	13-1/4	795 +/-5	31-5/16	2289	90-1/8
5	337	13-1/4	795 +/-5	31-5/16	2769	109


Hot gas defrost dimensions						
# Fans	Height (H)		Width (F)		Length (L)	
	mm	in	mm	in	mm	in
2	337	13-1/4	795 +/-5	31-5/16	1530	60-1/4
3	337	13-1/4	795 +/-5	31-5/16	2010	79-1/8

Hot gas defrost dimensions						
# Fans	Height (H)		Width (F)		Length (L)	
	mm	in	mm	in	mm	in
4	337	13-1/4	795 +/-5	31-5/16	2489	98
5	337	13-1/4	795 +/-5	31-5/16	2969	116-7/8

2.3.2 Operating modes

Direct expansion (DX)

Inlets and outlets



No.	Designation
1	Inlet of refrigerant via expansion valve (throttle valve)
2	Distributor
3	Outlet of refrigerant

Operating principle

The liquid working fluid enters the evaporator (1) via the expansion valve at low temperature and low pressure and is evenly distributed in the piping system through a distributor (2). In the piping system, the working fluid absorbs heat from the ambient air over the entire heat exchanger surface and evaporates. The compressor sucks in the gaseous working fluid and the working fluid leaves the evaporator via the outlet (3). The working fluid is compressed under high pressure in the compressor, thus raising the temperature level. The working fluid is liquefied again in the condenser. During this process, it releases the absorbed evaporation and compressor heat again. The expansion valve expands the working fluid, and the cycle starts again from the beginning.

2.4 Fan motor

Safety

SAFETY INSTRUCTIONS

Operate the unit once a month at full speed for at least three hours so that the bearings move and any penetrated condensate can evaporate.

SAFETY INSTRUCTIONS

With fans with an IP54 rating or higher, open the existing closed condensation water holes at least once a month.

⚠ CAUTION



RISK OF INJURY!

Operating the fan at wrong speeds may result in unexpected oscillations, vibrations and resonances. Parts of the fan can break, which can injure bystanders.

- Connect the fans in the terminal box in acc. with the motor connection wiring diagram and check for proper connection.
- Perform acceptance test of the fans.
- Check the fan unit regularly in acc. with the inspection and maintenance schedule.

EC technology

Please inform yourself about general differences between EC and AC technology.

The EC fans can be operated either at a fixed fan speed or via analogue 0 – 10 V signal. For the 0 – 10 V control, all (1 – 5) EC fans are grouped on site and wired to terminal box with printed circuit board. For operation, a supply line for the power supply must be laid on site. The intended speed is clearly linked to the type designation and already set accordingly via jumpers in the terminal box. Refer to the order documents for the exact value.

3 Safety

3.1 Intended/improper use

3.1.1 Intended use

Intended use

Güntner Dual COMPACT units are intended for installation in a refrigerating plant used for cooling and circulating the room air, in commercial applications such as processing rooms, picking areas, corridors, showrooms or rooms with temperature 0 °C.

The owner of the cooling plant determines the operating point.

The nameplate indicates the permissible fluid and the permissible pressure.

3.1.2 Operating conditions

Safety measures

Observe the following to avoid personal injury, environmental damage and damage to property in acc. with the state of the art:

- The unit must be used only in acc. with the proper intended use.
- Maintain and clean the unit regularly (see section "Maintenance and cleaning").
- Ensure that the working fluid and unit type do not deviate from the information specified in the order documents when operating, monitoring and maintaining the system.
- Ensure that maintenance measures are performed in compliance with the system's operating instructions.
- Operate the unit only with the working fluids indicated on the nameplate (fluid group and state). Filling the unit with a different fluid is permitted only with the prior written consent of the manufacturer.
- The maximum permissible operating pressure stated on the nameplate must NOT be exceeded.
- Work on the unit must not be performed without the personal protective equipment (PPE) specified in these operating instructions.

3.1.3 Improper use

General

The unit is being used improperly if:

- an unspecified working fluid, an unspecified pressure, an unspecified temperature and/or an unspecified connecting piping not prescribed in acc. with the instructions are used,
- the unit is not completely disconnected for cleaning/maintenance purposes,
- the main dimensions, weight, distances and recommended fixing sizes are not taken into account/adhered to during mounting,
- the supply line (electric) is fused or dimensioned incorrectly on site,
- the wrong fixing elements or not all of the fixing points provided were used for mounting,
- swarf falls into the pipe (when cutting off the connection piece without using a pipe cutter),

- the unit is defrosted improperly, which leads to severe icing on core tubes, fins and in the connection compartment, which in turn can lead to cracks and fractures in refrigerating system components,
- the unit is operated in an environment or for capacity requirements (e.g. aggressive/corrosive environment; capacity range) the unit with its material combination or capacity is not designed for, or which do not correspond to the intended use.

Improper modifications

The unit must not be modified without prior written consent of Güntner U.S. LLC. Modifications to the unit are:


- Change of the operating point (the specified operating point is indicated in the order-related documents)
- Changing the fan capacity (air volume)
- Changing the volume of the working fluid passing through
- Changeover to a different working fluid
- Changeover of the originally designed defrost technology
- Modification to load-bearing components or the casing (remodelling/changes)

Improper operation

The unit must not be operated if it is damaged or shows signs of faults. All damage and faults must be reported to Güntner U.S. LLC immediately and must be rectified without delay.

3.2 Labelling on the packaging/the unit

3.2.1 Packaging overview



Positioning of the labels on the packaging

3.2.2 Signs and notes on the packaging




Label 1: 60005 – Use strap only here




Label 2: 70489 – Please recycle


3.2.3 Unit overview




Labels on the front side




Labels on the left side



Labels on the connection side



Labels on the right side




Labels on the bend side

3.2.4 Signs and notes on the unit

Safety signs and specific notes on the unit




Label 1: 7067* - Güntner logo



Label 2: 4722.1 - Minimum height of the evaporator from the floor




Label 3: 574* - Fan number



Label 4: 940 - Transportation pressure




Label 5: 5608 - Fan rotation left



Label 6: 5609 - Fan rotation right



Label 7: 5735.1 - Cleaning agent instructions



Label 8: 4721 - Cold storage use



Label 9: 4723.1 - Grounding



Label 10: 5607 - Warning of electric shock



Label 11: 4628.1 - Danger of hazardous voltage



Label 12: 4720 - Caution of hot parts



Label 13: 5737 - Inlet connection



Label 14: 5477.1 - Caution of motor overload



Label 15: 68844 - Attention of copper conductors use



Label 16: 5738 - Outlet connection

3.3 Basic safety instructions

3.3.1 Please note

⚠ WARNING

Prior to all work on the unit and in case of danger respectively:

- Completely disconnect the unit and secure it against unintentional restart (lockable emergency stop switch is available or must be provided by the customer)
- Refer to the order documents for the permissible working fluid
- Observe the safety data sheets for the working fluid
- Wear personal protective equipment (PPE)

SAFETY INSTRUCTIONS

Only persons who meet the requirements for the personnel may work in the area of the unit (see section "Definition of the target group and requirements").
The operator must prevent persons under the age of 14 and unauthorised persons from gaining access to the unit.

3.3.2 Electrical hazard

⚠ DANGER



ELECTRICAL VOLTAGE!

A short-circuit on the electrical connections and direct or indirect contact with live parts of the unit (including accessories and supply lines) can cause severe injury or even death. In addition, overvoltage or overheating of the electrical parts installed in the unit can result in fires which in turn can cause smoke inhalation injuries among bystanders.

The risk of electric shocks and short circuits increases with the degradation of insulating material due to environmental influences or mechanical and/or deliberate damage.

- Completely disconnect the supply line before performing electrical work on the unit (see the documentation for the plant as a whole).
- Work on the unit and the connection and control configuration must be performed by specialist staff.
- Check electrical components regularly, including testing in acc. with ASHRAE standards and relevant national standards. Consider the information provided in the connection diagram.
- Properly connect the unit to the building's earthing system.
- Perform earthing checks and visual inspections of the earthing points regularly.



3.3.3 Hazard due to working fluids

Working fluids pose various residual risks such as irritation, suffocation, poisoning, burns, frostbite, fire hazard and/or explosion hazard. Observe the following safety measures:

- Observe the safety data sheet of the working fluid.
- Comply with the safety regulations for the system in acc. with the ASHRAE standards.
- Observe the pressure and temperature specified on the nameplate.
- Observe the type of fluid, the fluid charge and material selection in acc. with the technical data.
- Before performing any maintenance work, ensure that the unit is depressurised. Completely drain any working fluid from the unit if necessary.

⚠ WARNING		
	EXPLOSION HAZARD! FIRE HAZARD! RISK OF SUFFOCATION! RISK OF POISONING! RISK OF FROSTBITE! When working on the pipes of the heat exchanger (e.g. soldering or welding work), or if the flammable working fluid escapes through leaks and forms an explosive mixture over time, the working fluid catches fire or explodes and injures bystanders.	
	Bystanders may inhale the escaped working fluid. Inhaling the working fluid causes anything from breathing problems to suffocation or poisoning.	
	Contact with the working fluid can cause frostbite and/or irritation.	
	Leakage of the working fluid can also lead to environmental damage.	
	• Drain the unit before commissioning or transporting. • Ensure that the operator provides appropriate fire-fighting equipment for soldering and welding work. • Ensure that the plant is designed in such a way that the unit can be filled/emptied safely. • Do not fill with a working fluid other than that specified in acc. with the order documents! • Take measures to prevent high working fluid concentrations on site. • Monitor the degree of icing regularly and observe the defrosting requirements. • Check the unit regularly for leaks and leakage (see section "Inspection/maintenance schedule"). Avoid leaks and leakage and, if necessary, have them fixed as quickly as possible by an expert. • Only put the unit back into operation when all leaks have been repaired. • Pay attention to the risk of ignition of oil residues carried over. • Avoid all sources of ignition when working! • Observe all applicable standards and directives with regard to waste disposal. • Wear personal protective equipment (PPE), including respiratory protection if necessary (see safety data sheet for the relevant working fluid).	

3.3.4 Hazard due to vibrations

⚠ WARNING





EXPLOSION HAZARD, FIRE HAZARD, RISK OF PERSONAL INJURY AND DAMAGE TO PROPERTY CAUSED BY EJECTED OBJECTS!

A component, a chunk of ice or the complete fan unit loosens because of vibrations/oscillations/imbalance and

- injures bystanders or
- is thrown out of the unit by the fan's rotating movement and damages the heat exchanger whereby
 - the working fluid escapes and gets onto the skin of bystanders and/or is inhaled by bystanders (see section "Hazard due to working fluids"), or
 - the working fluid ignites (with flammable working fluids) and injures bystanders, or
 - a core tube that is under pressure explodes and the resulting pressure wave injures bystanders.

Take the following measures:

- Fans, components and pipes in the system must be designed, constructed and integrated in such a way that risks caused by vibrations are reduced to a minimum.
- Connect the fans in acc. with the motor connection diagram in the terminal box, check the connection and perform acceptance test of the fans.
- Check the fan unit regularly in acc. with the inspection and maintenance schedule.
- Keep the unit free of ice.
- Check the unit and especially the proper functioning of the fans after standstill periods.

⚠ WARNING



ADVERSE HEALTH EFFECTS AND DAMAGE TO PROPERTY CAUSED BY VIBRATIONS!

The operation of fans regularly causes vibrations that are increased by imbalances resulting from impurities, frost accumulation, icing or damage of fan blades. These vibrations are transmitted to the building and the unit and can result in damage to the building and the unit, and to the unit's suspension, the pressurised pipes/components and the system's components connected to the unit.

This can result in leakage of the working fluid and adverse health effects (see section "Hazard due to working fluids").

- Check the fan blades and protection guards regularly for impurities, frost accumulation, icing and snow accumulation, and make sure the fans run smoothly.

3.3.5 Hazard due to pressurized parts

⚠ WARNING	
 	EXPLOSION HAZARD! PERSONAL INJURY AND DAMAGE TO PROPERTY DURING OPERATION OR MAINTENANCE! The pressure in the heat exchanger exceeds the specified limit values (e.g. due to improper installation) and results in an explosion or breakage of pressurized pipes/components. This causes objects to be ejected and/or working fluid to be released, resulting in personal injury or damage to property. • Comply with all regulations regarding installation, operation, maintenance and maximum permissible operating pressure. • Drain the unit before commissioning or transporting. • Ensure that the operator provides appropriate firefighting equipment for soldering and welding work. • Ensure that the plant is designed in such a way that the unit can be filled/emptied safely. • Monitor the degree of icing regularly and observe the defrosting requirements.

3.3.6 Thermal hazard

⚠ WARNING	
 	RISK OF BURNS OR RISK OF FROSTBITE! Contact with the working fluid (e.g. during filling/drain- ing) or with the unit surface or pipes can cause severe burns/frostbite. • Wear personal protective equipment (PPE). • Monitor the degree of icing regularly and observe the defrosting requirements. • Retrofit a thermal insulation to the pipes and the connection system as required. • If necessary, wait until the temperature has equalised to the ambient temperature before starting to work.  

3.3.7 Mechanical hazard

WARNING



RISK OF INJURY!

Due to overloading or external influences such as extreme, impermissible ice loads on the unit, the unit loses the holding force of the attachment and tips over or falls down, or structural failure occurs and the unit breaks apart. Bystanders are seriously injured.

- If the unit reaches its load limits (e.g. ice load), defrost the unit properly and perform an inspection of the unit.
- Install the units at the corresponding fixing points. The operator or installer is responsible for ensuring that the connecting elements (screw connections) are of an adequate strength.
- Tighten the fixing bolts evenly to achieve an even load distribution on the unit's fastenings.
- Anchor the unit in its fixing position to prevent it from moving.
- Secure fixing bolts against loosening by means of appropriate locking devices.
- Regularly check all fixing bolts and attachments for corrosion damage, loading-bearing capacity and structural integrity, and replace them if necessary, especially before and after lifting the unit.

WARNING



RISK DUE TO FALLING OR EJECTED OBJECTS!

A component or chunk of ice can come loose owing to vibrations, is being ejected from the unit because of the fan rotation and can injure bystanders.

- Check the fan unit regularly in acc. with the inspection and maintenance schedule.
- Check the unit and especially the proper functioning of the fans after standstill periods.
- Defrost the unit properly and keep it free of ice (ice thickness $\geq 1/16$ in (1 mm) not permissible).

⚠ WARNING		
 	RISK OF CUTTING AND CRUSHING! Persons can cut or otherwise injure themselves on the packaging (e.g. wood) or on sharp edges of the unit (e.g. sheet metal edges/fins) or the accessories. There is a risk of crushing when the unit is open. • Wear personal protective equipment (PPE). • The hinged or removable components (e.g. side plates/trays (if any)) may be opened only by trained specialist staff and only for the purpose of maintenance and repair. Once the work has been completed, the components must be closed and secured against unintentional or unauthorised opening.	 

3.3.8 Hazard due to fans

⚠ WARNING		
  	DANGER OF PULLING IN, RISK OF CRUSHING AND DANGER OF CUTTING OFF! Limbs can be caught by the running fan or pulled into the running fan and injured (e.g. crushed) or severed. Hair and clothing can be pulled in the running fan and cut off. • Completely disconnect the unit and secure it against unintentional restart before performing any work. • Ensure that the fans are connected in acc. with the motor connection diagram in the terminal box, then perform an acceptance test of the fans. • Operate the fans only with protection guards. • The protection guards must be opened by trained specialist staff and only for maintenance and repair purposes. • Check the fan unit regularly in acc. with the inspection and maintenance schedule. • Do not wear any loose clothing or jewellery. Secure long hair on the head. • Prior to transportation, the transport screws must be secured to the fan plate and removed once transportation is complete. • Wear personal protective equipment (PPE). • Stop the unit immediately if a missing or ineffective safety device is detected. • Check the unit and especially the proper functioning of the fans after standstill periods. • Keep the unit free of ice.	  

3.3.9 Other hazards

⚠ WARNING		
	RISK OF HEARING DAMAGE! Persons who spend long periods in the vicinity of the unit can suffer hearing damage, discomfort and stress as the unit produces noise levels (sound pressure levels) of over 70 dB(A).	
	• Wear personal protective equipment. • Observe the requirements of local authorities. • The manufacturer of the system is obliged to position the unit in such a way that noise pollution is minimised. In addition, further suitable measures must be taken to minimise noise.	
⚠ CAUTION		
	RISK OF INFECTION! During operation, cleaning or defrosting of the unit, water can accumulate, especially in hard-to-reach areas with insufficient slope. Standing water, in turn, results in the formation and proliferation of germs which can be released into the ambient air when the unit is switched on again. This can infect bystanders and contaminate the refrigerated goods.	
	• The operator must ensure that the tray has a sufficient slope for water drainage and that the drain of the tray is kept clear. • Clean the unit regularly and observe hygiene regulations. • Define cleaning intervals in relation to the requirements of the respective applications.	

4 Transportation and unpacking

4.1 Safety instructions for transportation and unpacking

⚠ WARNING		
	RISK OF INJURY OWING TO STRONG IMPACTS! RISK OF CRUSHING AND SHEARING! The following hazards may occur: • During transporting or manoeuvring the means of transport, bystanders are caught by the unit. This causes serious impact injuries, or limbs are sheared off/crushed. • Bystanders get under the unit or are caught by a falling component/unit and lose limbs or are crushed. • The unit loses its stability due to accelerations during transportation and falls over or falls from the goods vehicle. Bystanders are seriously injured. • Attempting to transport the unit by hand may result in injury (e.g. spinal injury) due to excessive load.	
	Take the following measures: • Transportation including loading and unloading only by specialist staff. • Do not stand in the loading/danger zone under or in the vicinity of suspended loads. • Ensure that the unit is protected against slipping and mechanical damage. • Remove foreign material before lifting the unit, and sweep off snow. • Ensure that the unit is not filled during transportation. • Suspend or position the unit so that it has a stable centre of gravity. • Use appropriate lifting or tie-down points. • Use suitable tools and working equipment. • Do not lift the unit in strong winds. • Observe maximum permissible total weight. • Wear personal protective equipment.	
		
		
		

⚠ CAUTION



RISK OF SLIPPING!

The hose of the condensation water pump has slipped due to the transportation and no longer sits correctly at the suction point in the tray. As a result, the pump can no longer remove water by suction, the water escapes from the unit and drips onto the floor. Persons standing under the unit can slip because of the escaped water.

- Perform a visual inspection of the pump regularly. Check the hose for proper fit at the suction point in the tray and for clogging.

⚠ CAUTION



RISK OF INJURY WHEN UNPACKING!

Dust and wood particles can get into the eyes when removing the film.

- Wear personal protective equipment.
- Use appropriate tools.



NOTICE

The lifting capacity of the means of transport must be at least 1.5 times the weight of the unit. Do not use connection pieces and outlet headers as attachment points for lifting, pulling, fixing and climbing. This can result in leakage.

SAFETY INSTRUCTIONS

Observe all basic safety instructions (see section "Basic safety instructions").

4.2 Transportation and storage of the unit

4.2.1 Transportation of the unit

SAFETY INSTRUCTIONS

Read and observe the transportation sign on the unit packaging!

Permanent mechanical load caused by uneven road surfaces and potholes, and vibrations during ship transportation, can result in transportation damage.

- Mounted parts that can be induced to vibrate – particularly fans and bases (if any) – must be removed prior to ship transportation or in countries with critical traffic routes.
- Supports of outlet headers and flanges must be added if required.
- After the transportation, all bolted connections, especially on EC fan terminal boxes, must be checked and retightened if necessary (for tightening torque values, see section "Fans").


⇒ Unload the unit.

⇒ Transport the packed unit with suitable transportation equipment (e.g. industrial truck with forks) to the final place of installation.

NOTE: Place the unit on a pallet for transportation with an industrial truck with forks.

SAFETY INSTRUCTIONS

Before lifting the pallet with an industrial truck with forks, slide the forks far enough underneath the open spaces of the pallet so that they reach to the end of the pallet.




4.2.2 Storing the unit prior to installation

- ⇒ Protect the unit against dust, dirt, moisture and wetness, damage and other harmful influences until it is mounted.
- ⇒ For storage periods of more than one month: Operate the fans at least once a month at full speed for at least three hours so that the bearings move and any penetrated condensate can evaporate. Check, once a month and prior to installation, if the transportation pressure is still present to ensure that the unit is leak-tight. If the pressure is too low or if there is no transportation pressure at all, be sure to contact the service department of the manufacturer. Before moving the unit to the installation site, check the load capacity and structural integrity of the crane lugs and replace them if required. Store the unit only in its original packaging until installation.
- ⇒ If the unit installation is delayed beyond the initial deadline scheduled for installation: Protect the unit against weather and other harmful effects and dirt with an appropriate tarpaulin. In this context, ensure good ventilation of the unit.


4.3 Unpacking the unit

Wooden packaging

The units are delivered in the installation position and with mounted tray.



Unpacking the unit



If several units are delivered, up to three wooden packaging will be stacked for delivery.

- ⇒ Remove the wooden crates on the sides and the top.
- ⇒ Remove the plastic cover from the unit.
- ⇒ Leave the unit on the transportation frame.

After unpacking

- ⇒ Dispose of packaging material.
- ⇒ Check scope of delivery for completeness. For the scope of delivery, refer to the order documents.
- ⇒ State transportation damages and/or missing parts on the delivery notes. Immediately notify the manufacturer in writing about the matter. Damaged fins can be repaired on site using a fin comb.
- ⇒ Check the transportation pressure (see below).

SAFETY INSTRUCTIONS

Güntner U.S. LLC's transportation packaging is made from environmentally sound material and is suitable for recycling.

4.4 Checking the transportation pressure

Introduction

The section applies only to units supplied with transportation pressure.

All units are delivered by the manufacturer with approx. 14.5 psi (1 bar) of transportation pressure (cleaned and dehumidified air). The transportation pressure is used to check the leak tightness.

Specific hazards

⚠ CAUTION




RISK OF DAMAGE TO PROPERTY!

The unit is pressurised! An unpressurised unit indicates a leak due to transport damage.


- Do not put the unit into operation!
- Immediately report any pressure drop of the unit to the manufacturer and note it on the delivery note.

Procedure after receiving the unit


- ⇒ Read the transportation pressure on the Schrader valve (pressure measurement).




- ⇒ Loosen both bolts on the inlet side at the upper corners of the side plate.




- ⇒ Slide the plate upwards.
- ⇒ To remove, pull the plate forwards.



- ⇒ Note the details on the tag of the valve.




- ⇒ Loosen the cap of the valve.



- ⇒ Check if there is transportation pressure.

Procedure immediately before the installation



In the case of factory-sealed pipe ends without flanges

- ⇒ Check the transportation pressure (attach a pressure gauge to the Schrader valve and read the pressure) and then release it.
 - ⇒ Cut off the sealed pipe ends without flanges from the pipes (e.g. with a suitable saw).
- Caution!** The sealed pipe ends must not be cut off more than 13/16 in (20 mm) from the end.

5 Installation and commissioning

5.1 Safety instructions for installation and commissioning

Please note

SAFETY INSTRUCTIONS
Observe the basic safety instructions and the safety instructions for transportation (see sections "Basic safety instructions" and "Safety instructions for transportation and unpacking").
SAFETY INSTRUCTIONS
Observe the earthing marking on the unit. Ensure professional equipotential bonding to protect any warranty claims.
SAFETY INSTRUCTIONS
Mounting/installation must be performed by competent persons. The manufacturer's warranty does not cover damage resulting from improper installation.
SAFETY INSTRUCTIONS
During filling and after filling the system, properly vent the heat exchanger. To do this, keep the vent connections open until no more air escapes from the unit! Observe the safety data sheets of the working fluid used!
SAFETY INSTRUCTIONS
After commissioning, document the installation and settings and have them signed by the responsible persons.

Specific hazards

NOTICE
 RISK OF DAMAGE TO PROPERTY! In order to avoid stray currents, heat exchanger tubes, casing parts and the like must not be used as return line when performing welding work as these load-bearing components and lifting accessories are not designed for high welding currents. If not observed, unintended or improper current flow can damage heat exchanger pipes of the unit and lead to damage during operation. Securely connect the insulated welding return line to the workpiece to be welded directly at the welding point.

⚠ CAUTION



FIRE HAZARD!

As a result of high tolerance errors, the fan blade can rub against the nozzle when connecting the fans. This causes sparks and may ignite surrounding flammable materials.

- The tray has to be pushed upwards every time it is closed so that the quick-release couplings named “SnapLocs” (ensuring the tray is locked) click into place.

NOTICE

RISK OF DAMAGE TO PROPERTY!

In order to avoid stray currents, heat exchanger tubes, casing parts and the like must not be used as return line when performing welding work as these load-bearing components and lifting accessories are not designed for high welding currents.

If not observed, unintended or improper current flow can damage heat exchanger pipes of the unit and lead to damage during operation.

- Securely connect the insulated welding return line to the workpiece to be welded directly at the welding point.

NOTICE

RISK OF DAMAGE TO PROPERTY!

To prevent damage to the heat exchangers, always connect them without force and torque.

There must be no forces or moments acting on the heat exchanger at any time. Failure to observe this can result in leaks and further damage to the heat exchanger in the short and medium term.

- Ensure that the outlet headers and flanges (if any) are not used as a climbing aid. They are not designed for external forces.
- Ensure that no forces or moments act on the heat exchanger at any time by using suitable fixed bearings during pipe installation.

5.2 Requirements for the place of installation

Dimensions/weights

For dimensions and weights, refer to the order documents.

Environmental conditions

The unit is designed for the following ambient conditions:

- Ambient temperatures ranging from -40 °F to +104 °F (-40 °C to +40 °C)
- At fluid temperatures below +32 °F (0 °C), frost and ice is likely to form.

The material selection of all components must be suitable for the local conditions.

Load limits

The unit is subject to the following load limits:

- Max. ice load on the heat exchanger: 1/16 in (1 mm) on the fins
- Max. ice load on casing parts and accessory parts: 0 in (0 mm)
- Max. ice load on refrigerating system components: 1/16 in (1 mm)

Installation conditions


- ⇒ The place of installation must have sufficient load-bearing capacity.
- ⇒ A stable and flat floor/ceiling is required for mounting.
- ⇒ The layout plan must be drawn up by the system operator.
- ⇒ Position the unit in such a way that it is safe to reach and cannot be damaged by internal traffic, transportation processes or other environmental hazard sources (e.g. processes at the place of installation).
- ⇒ Position the units in such a way that the air flow is not impeded by obstacles.
- ⇒ Place the unit so that it can be monitored and checked from all sides at all times.
- ⇒ Ensure that sufficient space is available for maintenance.
- ⇒ Ensure that all working fluid-carrying components, connections, shut-off devices and pipes and all electrical connections and lines are easy to access.
- ⇒ If electric defrost is used, ensure that there is free space for unobstructed exchanging of heating rods (accessory at customer's request).
- ⇒ Ensure that the labelling of the pipes is easily visible.
- ⇒ Ensure that there is sufficient free space on the side of the unit (e.g. the side distance from the unit to any possible obstructions) and under the unit so that the hinged side plates and the tray can be opened and closed in a safe and obstruction-free manner.
- ⇒ The unit must be securely fixed at all fixing points without vibration.

SAFETY INSTRUCTIONS

The operator or installer of the equipment is responsible for ensuring that the bolted connections are of an adequate strength.


Mounting overview

Schematics without options/mounted parts/accessories:




Minimum distance to the wall and between the units:

The minimum distance corresponds to the length of the unit so that the unit does not have to be removed when replacing or retrofitting heating rods.



Free air flow



Ensuring the proper functioning of the equipment:

- ⇒ Position the unit centrally on the longitudinal axis of the room.
- ⇒ Ensure that the air flow can circulate freely.
- ⇒ Keep a minimum distance of 39-3/8 in (1 m) between the unit and the refrigerated goods.

5.3 Installation of the unit

5.3.1 Installing the unit

Required staff

- The installation must be performed by at least two people.

Auxiliary equipment/tools


- Lifting accessories and lifting gear
- Climbing aids
- Fasteners (fixing bolts/nuts, washers and rawlplugs)
- Master gauge for holes (see section "Versions")
- Writing materials
- Required measuring equipment
- Drilling tool
- Spanner or appropriate assembly tools for screws and nuts

Note: Choose the tools that are best suited to the task at hand.

Provisions for fixing


- Prevent mechanical stress on the unit as follows:
 - Ensure that all fixing points are at the same distance from the fixing level and that this distance is maintained permanently even under load.
- At the place of installation, bolt the units into place via all available fixing points using fixing bolts with washers. The fixing points must support the weight of the respective unit. The operator or installer of the equipment is responsible for ensuring that the bolted connections are of an adequate strength.
- Observe the following instructions when fixing the units:
 - The diameters of the mounting holes have been statically determined by the manufacturer; use suitable fixing bolts and washers. When calculating the bearing strength, it is imperative to take into account the total weight of the unit (= structural weight of the unit + weight of tube volume + additional weight such as moisture, ice and dirt).
 - Secure fixing bolts against loosening by means of appropriate locking devices.
 - The fixing bolts must not be overtightened.
 - All fixing screws must be tightened equally.
- Fix the unit in position and secure it against moving.
- Ensure that the drip water drains properly. Set up the unit horizontally in a level position. The units are delivered in the installation position and with mounted tray.
- Use the fixing points provided to fix the unit. Tighten all fixing bolts evenly to achieve the most even load distribution possible.

Hole pattern



Procedure

Units with 2 – 5 fans



- ▶ Make holes for the screws in the ceiling in acc. with the hole pattern.
- ▶ Lift the unit on the transportation rack to the ceiling using lifting gear.
- ▶ Bolt the unit to the ceiling. Tighten all nuts evenly.
- ▶ Ensure that the tray does not unhinge.
- ▶ Ensure that both side panels are properly secured.

5.4 Connecting the unit

5.4.1 Connecting the unit to the plant

Safety

⚠ WARNING



RISK OF PERSONAL INJURY AND DAMAGE TO PROPERTY!

Improper connection to the system will result in leaks that will lead to the escape of working fluid and corresponding risks (see section "Hazard due to working fluids").


- Follow the instructions for connecting the unit and pipes.

SAFETY INSTRUCTIONS

Observe all safety instructions on the installation and commissioning (see section "Safety instructions for installation and commissioning").

Distributor connection (only applicable to CX)

Connect the distributor to the system in acc. with the following instructions:



SAFETY INSTRUCTIONS

After installation, check the capillary tubes of the distributor for free movement. Vibrations can result in mechanical damage and leaks. It is therefore essential to align or additionally secure the capillary tubes (e.g. using plastic cable ties).

Important notes on connecting the unit

- Regarding welding work: Observe the safety instructions on connecting the welding return line (see "Safety instructions for installation and commissioning").
- Perform soldering and welding work only on unpressurised units.
- Ensure that mechanical stresses and vibrations from the system are not transferred to the unit.
- It is imperative that working fluid connections are installed without tension and protected against linear thermal expansion and vibrations using horseshoe expansion joints or pipe compensators.
- Support the on-site piping with at least two fixed points before connecting to the unit.
- Never use pliers for the tray drain! Tighten by hand!


Installation notes on pipes

- The connections are easy to access thanks to the hinged tray.
- Keep the installation of pipes as short as possible; use as few bends as possible, and only those with large radii, to minimise the pressure drop.
- External loads must not act on the pipes and unit connections.
- Lay pipes (liquid and discharge lines, supply and return lines) separately from each other and insulate on both sides.
- Ensure that pipes are secured against vibrations, mechanical stresses and force transmission due to linear expansion.
- The free space around the unit must be large enough so that the following measures can be carried out:


- Regular maintenance of the components
- Checking of components, pipes and fittings
- Repairs
- It must be possible to shut off the unit if a leak occurs.

Procedure


- ⇒ Install the pipes in acc. with ASHRAE standards.
- ⇒ With copper, the connection to the system must be soldered.
- ⇒ With units with threaded connections/flanges, bolt the connections together.
- ⇒ In the case of threaded connections, prevent the pipe from twisting by holding it in place.
- ⇒ When brazing, observe the following:
 - Braze all connections!
 - Avoid end-to-end joints; use copper pipe ends expanded on one side (capillary brazing)!
 - Avoid leaks, braze conscientiously and carefully!
 - Avoid overheating when brazing (risk of excessive scaling)!
 - Use shielding gas when brazing (to avoid scaling)!



- ⇒ Tighten the condensate drain only by hand. Do not use pliers under any circumstances!
- ⇒ Always use a siphon.



- ⇒ For rooms with temperatures $> 0^{\circ}\text{C}$, install the siphon directly under the condensate drain.



- ⇒ For rooms with temperatures $< 0^{\circ}\text{C}$, install the siphon outside the room.


► After installation, check that the connections are tight.

5.4.2 Connecting the drain line to the tray

Requirements

- The diameter of the drip tray drain line must be at least that of the drip tray drain of the unit.
- The drip tray drain line should be laid with a downward slope of 3° to 5° .


Installation notes



Pipe routing (schematic)

- Recommended pipe routings:
 - Continuation through 90° bend
 - Continuation downwards
- Sealing of the connected drain line with a flat gasket pressed on the pipe connectors.
 - Do not seal with Teflon tape
 - Do not seal with hemp

Overview



Connecting the drain line (schematic)

No.	Designation
1	Drain line
2	Connecting nut
3	Flat gasket
4	Drip tray drain


Procedure

- ⇒ Lay the drain line (1) without applying any tension
- ⇒ Insert the flat gasket (3) between the connecting nut (2) and the drip tray drain (4)
- ⇒ Tighten the connecting nut by hand.

NOTICE**RISK OF DAMAGE TO PROPERTY!**

When using pliers, the plastic thread can be damaged by overstretching. This will lead to leaks with dripping water damage to the goods to be cooled.

- Do not use pliers to tighten the connecting nut!



5.5 Electrically connecting and protecting the unit

Introduction

Each unit is designed for a specific fan speed in acc. with the data sheet and wired accordingly. Some fans provide the option of a second, reduced speed or a continuous control as a standard. For details, refer to the corresponding connection diagram. Changing the fan speed can have a negative impact on the thermodynamic configuration of the unit.

Interfaces

As interfaces to the electrical equipment, there are terminal boxes and switch cabinets for the electrical supply and signal exchange (see connection diagrams and manuals of the control systems).

Procedure

- ⇒ Connect the unit to the power supply in acc. with the connection diagram.
- ⇒ Use the prepared thermocontacts to protect the motors to safeguard any warranty claims.
- ⇒ If electric defrosting is used, connect the electrical feeds for the heating rods in acc. with the connection diagram when required.

- ⇒ Place the defrost limit sensor in acc. with section "Defrosting functions".
- ⇒ Perform all electrical lines in acc. with the connection diagram, taking into consideration the ASHRAE standards and national regulations respectively.

5.6 Connection diagrams

Connection diagram for fan motor

See inside the motor terminal box at the fan or in the terminal box of the unit
See order documents

Connection diagram for electric defrost (optional; accessory at customer's request)

See inside the terminal box of the electric defrost heater
See order documents

Connection diagram 0-10 V control

See inside the unit's terminal box
See order documents

5.7 Performing an acceptance test

Specific hazards

 WARNING	
	RISK OF PERSONAL INJURY AND DAMAGE TO PROPERTY! Escaping working fluid can cause personal injury (see safety instructions regarding working fluids in section "Basic safety instructions"). • Have the following acceptance test performed by a competent person before commissioning the unit, after making important changes to the unit and after replacing the unit.

Requirements

- The acceptance test must be performed by the manufacturer of the system!
- The temperature and humidity at the place of installation correspond to the permissible operating range (see section "Technical data of the unit").

When to perform an acceptance test

- Before commissioning the unit
- After making important changes to the unit
- After replacing the unit

Procedure

- ⇒ Ensure that sufficient air can be sucked in and blown out.
- ⇒ Ensure the power supply is sufficiently dimensioned: Compare the connection diagram of the unit with the connection diagrams of the complete system.
- ⇒ Ensure that a professional equipotential bonding has been performed.
- ⇒ Check the unit for vibrations and movements that could be caused by the operation of the fans or the plant. Eliminate vibrations and external forces, following consultation with the manufacturer if required.
- ⇒ Perform a visual inspection of the structural design, the brackets and fastenings (materials, connections), the operability and the arrangement of the fittings.
- ⇒ Check all threaded connections on the fans and tighten them if necessary in acc. with the following table.

Screw/bolt	Type of bolt	Tightening torque
M6 (property class 8.8)	Cage nut/snap nut	88.5 lb-in (10 Nm)
M8 (property class 8.8)	Cage nut	204 lb-in (23 Nm)
M8	Nut (SST)	204 lb-in (23 Nm)

- ⇒ Check all other threaded connections and tighten if necessary.
- ⇒ Check the pipe connections.
- ⇒ Check that working fluid-carrying pipes are laid correctly.
- ⇒ Ensure that the unit is protected against mechanical damage.
- ⇒ Ensure the unit is protected against excessive heating up and cooling down.
- ⇒ Check the protection guards for damage.
- ⇒ Ensure that the unit can be inspected at any time and is always freely accessible:
 - Is the unit positioned so that it can be monitored and checked from all sides at all times?
 - Is sufficient space available for maintenance?
 - Are all working fluid-carrying components, connections and pipes and all electrical connections and lines easy to access?
 - Are the pipe identifications easily visible?
- ⇒ Check heat exchanger surfaces for dirt and clean if necessary (see section "Cleaning the coil").
- ⇒ Perform a function test on the fans (rotation direction, power consumption).
- ⇒ Check the wiring of the fans and the optional electric defrost heating for damage.
- ⇒ Check the quality and execution of all connections (soldered connections, electrical connections and fixing connections).
- ⇒ Be sure to perform a pressure test in acc. with ASHRAE standards.
- ⇒ Perform a system test in acc. with the locally applicable regulations, e.g. ASHRAE standards for the European region.
- ⇒ Check the corrosion protection: Perform a visual inspection of all pipes, components and component holders that are not heat-insulated. Document and archive the test results.

- ⇒ Perform a test run. Observe and check the unit during the test run, in particular for:
 - Quiet running of the fans (bearing noises, contact noises, imbalances, among other things)
 - Current consumption of the fans
 - Leaks

Procedure in case of defects

- ⇒ Report all defects to the manufacturer immediately.
- ⇒ Rectify the defects only upon consultation with the manufacturer.

Check after 48 operating hours

- ⇒ Check the unit and the unit's interaction with the system (cooling equipment and refrigeration system) again after approx. 48 operating hours, especially at the connections and at the fans.
- ⇒ Document the test result.

6 Operation

6.1 Safety instructions for operation

Please note

SAFETY INSTRUCTIONS

Observe the basic safety instructions (see section "Basic safety instructions").

Specific hazards

⚠ WARNING



RISK OF PERSONAL INJURY AND DAMAGE TO PROPERTY!

Escaping working fluid can cause personal injury (see section "Hazard due to working fluids").

- Put the unit into operation only if all requirements are met (see section "Putting the unit into operation").
- Ensure that the maximum operating pressure is never exceeded (also after shutdown)!

NOTICE

DAMAGE TO PROPERTY CAUSED BY VIBRATIONS!

The vibrations caused by the unit make a building vibrate which, in turn, results in collapse of this building or in errors of other systems.

- In order to prevent overload during transport and resulting damage of the vibration dampers, the vibration dampers are supplied loose and can be mounted by the customer.
- Check the fans regularly and replace them if necessary (see section "Fans").

SAFETY INSTRUCTIONS

To prevent corrosion caused by stagnant water, units with water as working fluid must be put into operation within two weeks after filling.

6.2 Putting the unit into operation

Requirements

Put the unit into operation only if the following requirements are met:

- A thorough and complete initial cleaning has been performed to remove dirt caused by transport and installation.
- Safe filling is ensured.
- The unit has been properly installed and connected (see section "Installation of the unit").
- A full acceptance test has been performed (see section "Performing an acceptance test").

- The operational readiness has been checked, and the operating point has been set (see below).
- All prescribed safety measures have been taken.

Checking the operational readiness

- ⇒ Ensure that all electrical protective measures are operational.
- ⇒ Ensure that all working fluid-side connections are securely established.
- ⇒ Ensure that all electrical connections (fans) are securely established.
- ⇒ Ensure that the protection guards are attached to the fans.
- ⇒ Ensure that all threaded connections on the fans, the fixing bolts on the unit and all other threaded connections are tight.

Setting the operating point

- ⇒ For the parameters for setting the operating point, refer to the order documents.
- ⇒ Ensure that the specified operating point is maintained. For this, secure the operating elements for setting the operating point against access by unauthorised persons (e.g. by sealing, screwing on caps, removing the handwheels).

Procedure

- ⇒ Switch on the system including the electrical system (see the system's operating instructions).
- ⇒ Switch on the unit.
- ⇒ Open the valves on the inlet and outlet side of the system.
- ⇒ Activate the fans.
- ⇒ Put the drip tray drain line into operation.
- ⇒ Wait until the operating point is reached. Once the operating point is reached, the unit is ready to operate (see the system's operating instructions).

6.3 Taking the unit out of operation

Introduction

The units are components of a system, including the heat exchanger circuit. The unit is taken out of operation by switching off the system in accordance with the system's operating instructions.

SAFETY INSTRUCTIONS

When shutting down the unit, observe the max. operating pressure! When required, take precautions to ensure that it cannot be exceeded.

Procedure

- ⇒ Switch off the fans
- ⇒ Switch off the working fluid feed pump (if any)
- ⇒ Switch off the electrical installation

6.4 Shutting down the unit

Safety**SAFETY INSTRUCTIONS**

All refrigerants must be removed from the unit by suction and disposed of by an approved specialist company in the field of refrigeration.

Procedure

- ⇒ Shut the unit down (see above).
- ⇒ Secure the unit as follows:
 - Secure the fan motor drives and, in the case of electric defrosting, any heating rods against restart.
 - Secure the working fluid-carrying pipes against supply with working fluid.
 - Protect against damaging effects at the place of installation or intermediate storage location so that the unit's components are kept in good condition and the intended use and usability of the unit are maintained. To this end, appropriate storage conditions (see section "Storing the unit prior to installation") must be provided, precautionary corrosion protection measures must be taken, regular checks of the functionality of the fans must be performed and the shutdown unit must be checked regularly.
- ⇒ With refrigerants (CO₂) prior to disassembly/removal: Completely remove the working fluid from the unit by suction into a suitable refrigerant container, and completely drain the lubricating oil for refrigerating compressors if necessary.

If the system is shut down for a period of three weeks or longer, the following must be observed:

- ⇒ Completely disconnect the unit and indicate this accordingly.
- ⇒ Remove dirt and deposits from the outside and inside of the unit.
- ⇒ Store the unit in a place that is not exposed to sunlight. It is recommended to cover the air outlets of the fans to prevent dirt and deposits from entering.

SAFETY INSTRUCTIONS

Operate the fans for approx. 2 – 4 hours per month during idle times of one month or longer in order to maintain functionality.

6.5 Putting the unit back into operation after shutdown

Introduction

The unit must be put back into operation in acc. with the system-specific design as set out in the system's operating instructions.

Procedure

- ⇒ Test the unit's readiness for operation.
- ⇒ Perform a pressure test in acc. with ASHRAE standards and a visual inspection for corrosion protection.
- ⇒ Put the unit into operation (see section "Putting the unit into operation").

NOTICE

Water residues in a refrigerating plant can result in damage to property!

- Evacuate to ensure that a sufficient degree of dryness of the refrigeration circuit is achieved in acc. with the requirements of ASHRAE standards.

6.6 Defrosting

6.6.1 Defrosting functions

Introduction

Recommendations for controlling the defrosting cycle are given below. These recommendations should be adapted to the local conditions in the cold room in order to achieve optimum defrosting behaviour.

If several evaporators or air coolers are installed in a larger cold room, group defrosting can be useful. Here, the units are divided into several groups that are alternately taken out of cooling mode and defrosted. These groups should be arranged in such a way that the units in defrosting cycle and those in cooling mode interfere with each other as little as possible.

Recommended defrost sensor positioning

In order to achieve optimal defrosting (heat exchanger completely free, moisture entry into the cold room minimised), it is crucial to position the defrost sensor carefully. Place it in the fin surface that is visible from the outside (usually the air inlet) where defrosting is finished at the latest time. This is usually also the coldest point in the heat exchanger.

The final defrost temperature should range between approx. 41 °F and 46.4 °F (5 °C and 8 °C).

If the visible fin surface is on the air outlet side of the unit, the final defrost temperature must be set a little higher.

In case the final defrost temperature is set too low, "ice pockets" can build up due to repeated insufficient defrosting.

If the final defrost temperature is set too high, this can cause extreme water vapour formation, which in turn causes the formation of frost and ice around the unit.

SAFETY INSTRUCTIONS

The defrost sensor is clamped and fixed directly between two fins. Positioning in an existing contact/supporting tube is not permitted!
Check the position selected during the first defrosting cycles and adjust if necessary.
Check if the defrost sensor measures the correct temperature. With longer connecting cables, it may be required to correct the measured value.

Types of defrosting

The following defrosting types are feasible for the Dual COMPACT:

- Air defrosting
- Electric defrosting
- Hot gas defrosting

When defrosting with hot gas, the utilisation of the defrost heat can be improved by the optional double-wall insulation of the tray.

6.6.1.1 Air defrost

Operating principle

With units that are operated at a cold room temperature of at least +39.2 °F (+4 °C), defrosting by means of circulated room air is sufficient in most cases.

For this, the supply line of the working fluid is interrupted. The “warm” room air in combination with the fan waste heat ensures sufficient defrosting. As inherent to the functional principle, a certain degree of room cooling is thus maintained even during the defrosting process.

The frost accumulation increases the air velocity across the heat exchanger. If the fans installed in the unit allow it, their speed should be reduced during defrosting to such an extent that condensate carry-over in the air flow is prevented.

Start the refrigeration mode again only after complete defrosting as described above.

6.6.1.2 Electric defrost

Operating principle

Defrosting by means of electric heaters is simple, although the efficiency is higher with other methods.

In the heat exchanger, the heaters are placed in tubes named contact tubes in acc. with predefined rules. To heat the tray, these heaters are attached to the heating sheet by means of retaining profiles. The heat generated is transferred to the frost via the fins and the heating sheet respectively.

An on-site monitoring with a safety device (temperature limiter; to be planned for when designing the system) must be provided in acc. with national relevant standards to rule out the danger of the units overheating. Operation without temperature monitoring is forbidden. The power supply for electric defrosting must comply with the valid regulations. Refer to the connection diagram for the connection values and recommended fuse rating. In acc. with ASHRAE standards, electric defrost systems require working fluid displacement or an equivalent suction circuit to prevent the permissible pressure in the unit from being exceeded when using electric defrosting.

6.6.1.3 Hot gas defrost

Operating principle

The superheated hot gas downstream of the compressor can be used energetically to provide the required defrost heat. For this purpose, it is conveyed to the evaporator to be defrosted. There, its temperature reduces/it condenses while releasing heat.

Usually, the hot gas passes through those pipes of the heat exchanger that also serve to generate cold so that defrosting can be carried out quickly and in a targeted manner. Compared with electric defrosting, efficiency is significantly higher.

A sufficiently large quantity of hot gas must be available to heat the heat exchanger evenly. This is achieved by defrosting only a part of the installed evaporators.

Rule of thumb:

Normal temperature: 2 evaporators in cooling mode, 1 evaporator in defrosting cycle

Deep freezing: 3 evaporators in cooling mode, 1 evaporator in defrosting cycle

As standard, the piping that is optionally available ex works is designed in such a way that the hot gas first flows through the condensate tray and then through the heat exchanger. However, it can make sense to control the tray and the heat exchanger separately, e.g. in order to reheat the tray for improved condensate drain while the actual defrosting of the heat exchanger has already been completed.

The defrost heat is used more efficiently with double-wall insulation of the tray (optional).

Injection evaporator

The hot gas is fed to the heat exchanger via a distributor. If capillary tubes with a diameter of 3/16 in (4.0 mm or 5.0 mm) are used for cooling operation, a second distributor with a larger flow area is installed for the hot gas.

From a capillary diameter of 1/4 in (6.0 mm) for cooling operation, the existing distributor can be used for the hot gas. To this end, a T-piece is integrated in front of the Venturi distributor. Between the T-piece and the distributor, sufficient stabilisation distance of at least seven times the tube diameter is provided.

6.6.2 Defrosting the unit

Safety

WARNING



EXPLOSION HAZARD!

The fluid for defrosting with hot gas is pressurised. The fluid can escape explosively in the event of a leakage in the defrost circuit. Persons can be injured by the fluid or ejected objects.

- Use suitable joining technique: Solder with copper; weld with steel.
- Ensure that the operator provides appropriate firefighting equipment for soldering and welding work.
- Ensure on the system side that safe filling/emptying of the unit is guaranteed.
- The heat exchanger must be drained prior to works on the unit and transport respectively.

⚠ WARNING	
	RISK OF BURNS! Contact with the heating element during or some time after operation can cause burns (at temperatures above +113 °F (+45 °C)). • Use heating elements only for their intended purpose. • Wear personal protective equipment (PPE). • If necessary, wait until the temperature has equalised to the ambient temperature before starting to work.
	
⚠ CAUTION	
	RISK OF SLIPPING! During defrosting, condensation water forms that can drip onto the floor and subsequently freeze. There is a risk of slipping. • Ensure that the drain of the tray is kept clear.
NOTICE	
RISK OF DAMAGE TO PROPERTY! Non-compliance with the defrost instructions can result in cracks and breakage in the pipes and leakage of the working fluid. • Perform the defrosting process regularly to remove ice. • Comply with the defrosting requirements. • If necessary, retrofit thermal insulation to the pipes and the connection system. • If necessary, install trace heating on the pipes and the connection system.	
SAFETY INSTRUCTIONS	
Observe all safety instructions for operation (see section "Safety instructions for operation").	

Defrosting checks

As the local conditions have a very strong influence on the operating behaviour of the unit and the need for defrosting, the heat exchanger must be checked regularly and specifically for frost accumulation and/or icing during operation.

Procedure

- ⇒ If the frost thickness on the fins reaches 1/16 in (1 mm), defrost the unit to ensure proper functioning and reliable operation. The defrosting process can also be started earlier though.
- ⇒ Initiate the defrosting process in good time (see section "Defrost control").
- ⇒ Consider alternating operating states, e.g. changes of use at the place of installation.

- ⇒ Choose the right final defrost temperature.
- ⇒ Consider settling time and delayed fan start.

6.6.3 Factors influencing the defrosting process

Time interval between defrosting cycles

How often defrosting is necessary depends on many influencing factors, e.g.:

- Type of refrigerated goods
- Ambient temperature
- Temperature difference between the working fluid and the room
- Frequency of entering (opening the cold room door)
- Fin spacing

The following factors can require more frequent defrosting:

- Insufficient unit-wall distance
- Too small a distance between opposite units
- Unobstructed air flow disrupted by substructures on a flat cold room ceiling
- Air circulation in the cold room hindered by incorrect goods storage (stacked too high, too close to the wall, crosswise to the air flow direction)
- Final defrost temperature set incorrectly

When the defrosting process is finished, ensure that defrosting has been completed.

6.6.4 Defrost control

General rules

The defrosting process is started at pre-set intervals or in line with demand. The process completion must be verified twice (time/temperature and temperature/temperature).

The defrosting cycle can be divided into four stages:

- Pump-out phase/heating of working fluid
- Defrosting process
- Drip phase
- Freeze-on phase/delayed fan start

Pump-out phase/heating of working fluid:

The supply of the working fluid is interrupted while the “warm” room air flows across the heat exchanger. Any refrigerant still present inside the heat exchanger is evaporated or removed by suction. If a cold brine is used, it is preheated to room temperature.

Defrosting process:

The actual defrosting process takes place. The required heat is supplied in one of the following ways:

- Warm room air
- Electric heatings
- Hot gas

Depending on the system concept, different defrosting types can be used for the heat exchanger and the condensate tray.

Drip phase:

It takes about 10 – 15 minutes during which the defrost heat supplied is still retained in the unit. The ice water drips off completely and is drained via the condensation pipe.

Freeze-on phase/delayed fan start :

The cooling circuit is started without switching on the fans. This cools down the heat exchanger to operating temperature and prevents warm and humid air from entering the cold room.

6.7 Changeover to a different working fluid

Specific hazards

⚠ WARNING	
	RISK OF PERSONAL INJURY AND DAMAGE TO PROPERTY! Operating the unit with a different working fluid without the prior consent of the manufacturer can result in significant dangers (see section "Hazard due to working fluids"). • The unit must not be changed over to a different working fluid without prior written consent from the manufacturer.

Requirements for the working fluid

- Ensure that the unit manufacturer has agreed to the changeover.
- Ensure that the unit is filled with the correct working fluid.
- Ensure that all materials used in the unit are compatible with the new working fluid.
- Ensure that the permissible pressure is not exceeded.
- Check that the new working fluid can be used without requiring a new test certificate for the unit.
- Ensure that classification is complied with.
- Reset the safety device for the unit or replace it where necessary.
- Prevent mixtures with residues of working fluid and possibly oil.
- Change all information regarding the new working fluid accordingly.
- Change the complete documentation including these instructions and the system's operating instructions accordingly.

Procedure

- ⇒ Change the working fluid following written consent by Guntner U.S. LLC and in compliance with the requirements for the working fluid.
- ⇒ Perform an acceptance test (see section "Performing an acceptance test").

6.8 Troubleshooting

Safety instructions

SAFETY INSTRUCTIONS	
Observe all basic safety instructions and the safety instructions for operating the unit (see sections "Basic safety instructions" and "Safety instructions for operation"). Use suitable tools, protective clothing and safety devices.	

Hotline

Phone +1 (847) 781-0900

E-mail: dg-us-service@guentner.com

Troubleshooting table

The following table shows possible faults and the measures to correct them.

Fault	Possible cause(s)	Remedy
Fan motor not running	Power supply interrupted	Restore power supply
	Fan blade stuck	Enable fan to rotate freely
Bearing noises	Defective fan motor	Replace the fan
Unit vibrating	Defective fan blades	Replace fan blades
	Fan bracket loose	Tighten the fixings and replace them if necessary
Unit capacity is not achieved	Coil is very dirty, frosted, iced up on the air side	Clean, defrost the coil
	Fans not running properly or fail to operate	Repair or replace fans
	Working fluid pressurising defective (temperature and quantity insufficient)	Set the working fluid pressurising values (temperature and quantity) according to the design data
Working fluid escaping	Working fluid-carrying components of the unit are leaking	Switch off the working fluid supply and the fans, document the damage, rectify the leak (see section "Fixing leaks")
Defrosting in the coil very uneven	Malfunctions of the coil heating	Check the heating elements and replace them if necessary
Ice build-up/icing in the coil	Unit is not completely defrosted during a defrosting process	Extend defrosting process
Ice build-up/icing in the tray	Malfunctions of the tray heating and/or the lower coil heating	Check heating elements and replace them if required

Rectify faults

- ⇒ Close the main lines of the working fluid supply
- ⇒ Wear personal protective equipment (PPE)
- ⇒ Determine and document the size of the leak
- ⇒ If it is required to enter the room with respiratory protection, then
 - activate emergency ventilation,
 - shut off all working fluid supply lines.
- ⇒ Sound the alarm at the slightest suspicion of injured persons in connection with working fluid. First get persons to safety, then eliminate leaks (see section "Fixing leaks"). Close all doors to the room in which the working fluid is escaping.
- ⇒ Press the Emergency STOP switch. This switches off valves, motors and other components to prevent working fluid from escaping.
- ⇒ Close shut-off valves, especially on the liquid side, where possible section by section so that the working fluid volume in the leakage area is kept as low as possible.
- ⇒ If possible, siphon off or drain the system section concerned in a controlled manner, or move the working fluid to other parts of the system. Here too it must be ensured that no liquid working fluid is locked in by shutting off system sections.

7 Maintenance and cleaning

7.1 Safety instructions for maintenance and cleaning

Please note

SAFETY INSTRUCTIONS
Observe the basic safety instructions (see section "Basic safety instructions").
SAFETY INSTRUCTIONS
Non-compliance with the maintenance schedule can result in cracks and breakage in the pipes and leakage of the working fluid.
SAFETY INSTRUCTIONS
The operator is responsible for providing protective clothing for maintenance and cleaning.
SAFETY INSTRUCTIONS
The operator is responsible for selecting suitable cleaning agents, antifreeze agents und corrosion inhibitors, and for observing and complying with the manufacturers' instructions.

Specific hazards

⚠ DANGER		
	ELECTRICAL VOLTAGE! Cleaning using a jet of water or steam causes water to enter live components. This results in a short circuit at the electrical connections and/or a life-threatening electric shock. This, in turn, can cause severe injury or even death of bystanders.	
	• Completely disconnect the supply line before performing electrical work on the unit. • Do not point the water jet at live components (e.g. terminal box). • Do not use steam cleaners or high-pressure cleaners on live components. • Ensure that live components are not hit by water or vapour jets (cover if necessary). • Observe the cleaning pressures and distances when cleaning. • Work on the unit and the connection and control configuration must be performed by specialist staff. • Check electrical components regularly. • Perform earthing checks and visual inspections of the earthing points regularly. • Connect the unit to the building's earthing system in the proper manner.	

⚠ WARNING		
  	RISK DUE TO FALLING OR EJECTED OBJECTS! Parts, dirt and masses of water or ice can fall down when hinging the tray down and injure bystanders. • Keep the tray's drain clear at all times. • Completely disconnect the unit and secure it against unintentional restart before opening the tray. • Do not stand under the tray. • Wear personal protective equipment (PPE).	   
⚠ WARNING		
	RISK OF CRUSHING! When working in the vicinity of moving components such as the hinged tray, limbs can get caught between the components and be crushed. • Completely disconnect the unit before performing maintenance work, including opening the tray. • Secure the unit against unintentional restart. A lockable repair switch is available or to be provided by customer. Attach an appropriate warning label to the unit. • Wear personal protective equipment (PPE).	 

⚠ WARNING		
	RISK OF SLIPPING! Unit is cleaned using water at sub-zero temperatures. The water collects on the floor and ice builds up under the unit. Person slips and falls. • Operation and cleaning only by specialist staff. • The cleaning agents and methods must be adapted to the ambient temperatures. • Wear safety shoes.	
⚠ CAUTION		
	RISK OF DAMAGE TO THE EYES! During cleaning work, there is a risk of injury from the water or air jet, dust or chemical cleaning agents. • Wear safety goggles!	

7.2 Procedure prior to all maintenance work

Before performing any maintenance work, carry out the following safety measures:

- ⇒ Completely disconnect the unit and secure it against accidental switching on.
- ⇒ Drain or siphon off the coil (heat exchanger) of the unit.
- ⇒ Completely remove the working fluid from the leaky unit, especially prior to soldering and welding work.
- ⇒ Clean and blow out the coil (heat exchanger) of the unit.

7.3 Inspection/maintenance schedule

7.3.1 Unit

Measure	Means	Interval
Remove frost and perform partial cleaning	Mechanical	As required (visual inspection)
Perform complete cleaning	Warm water or environmentally safe cleaning agent that is compatible with the unit's materials	As required (visual inspection)
Testing in acc. with PED as prescribed by the accredited inspection bodies		Every 12 months

Measure	Means	Interval
Inspection of the system (leak tightness tests, among other things) in acc. with ASHRAE standards		Every 12 months
Check for leaks		Every 6 months
Check corrosion protection		Every 6 months
Check earthing concept		Every 6 months (visual inspection) Every 12 months (measurement)
Check that electrical connections, cables and components are not damaged (visual inspection)		Every 6 months
Check fastenings: Check all fasteners of the unit including any optional additions	Mechanical	Every 6 months
Check fixings and load-bearing elements (e.g. crane lug bolts) for corrosion and load-bearing capacity or structural integrity; replace them if necessary	Mechanical	Every 12 months
Check units with water/glycol working fluid for correct bleeding. Note: During the test, the pump must be running.		Every 6 months
For terminal boxes, check cable entries and their seals for damage and replace if necessary.		Every 6 months

7.3.2 Heat exchanger coil

External inspection

Have a competent person (recommendation: Güntner U.S. LLC) perform a regular external check (visual inspection) on the unit every 5 years.

Maintenance schedule

d = daily, w = weekly, m = monthly, y = yearly				
Work to be performed	d	w	m	y
Check the coil, tray and connection compartments for dirt, frost and ice accumulation.	X			

d = daily, w = weekly, m = monthly, y = yearly				
Work to be performed	d	w	m	y
- In the event of dirt accumulation: Clean the coil, tray and connection compartments (see section "Cleaning the coil"). - In the event of frost and ice accumulation: Defrost the coil, tray and connection system (see section "Defrosting the unit").				
Check return bends of the coil side as well as all connections and pipes inside the casing for icing. In case of icing: Defrost the unit (see section "Defrosting the unit").				X*
Check the coil's general condition. If damage is found: Rectify damage.		X		
Check the coil's operating point (see section "Installation and commissioning"). - If change in fan capacity is found: Restore required system-side conditions. - If change in surface temperatures is found: Restore required system-side conditions.			X	
Check the coil and connections for leak tightness. Repair unit sections affected (see section "Fixing leaks")				X*
Check the working fluid pressurising of the coil. Restore required system-side conditions.				X*
Check the coil for corrosion. Corrosion or damage on core tubes, fins, support structures, pipe connections, fastenings: Repair unit sections affected.				X*

*) Recommended: every six months

7.3.3 Fans

Maintenance schedule

d = daily, w = weekly, m = monthly, y = yearly				
Work to be performed	d	w	m	y
Check fans for dirt, frost and ice accumulation - In the event of dirt accumulation: Clean the fans (see section "Cleaning the fans") - In the event of frost and ice accumulation: Defrost the unit (see section "Defrosting the unit")	X			
Check the fan drive for quiet running - Vibrations on the unit: Eliminate imbalances - When required, tighten blade fixing devices and correct blade settings		X		
Check fan bearings (every six months by manually turning the rotor while the fan is switched off) Running noise and smoothness of running changes: Replace the fan			X	
Impeller: Corrosion on bolts (with threaded blades) Replace screws				X*

d = daily, w = weekly, m = monthly, y = yearly				
Work to be performed	d	w	m	y
Fan blades: Corrosion or damage on blades • Replace the fan				X*
EC fan terminal boxes: Check threaded connections • Retighten all threaded connections				X*

*) Recommended: every six months

7.4 Maintenance work

7.4.1 Fixing leaks

Procedure

- ⇒ Report any leaks on the unit to Güntner and have them fixed as quickly as possible by a competent person.
- ⇒ Perform all work including pressure, acceptance and functional test (see section "Performing an acceptance test").

7.4.2 Cleaning the unit

Introduction

For easier cleaning, some parts of the unit (e.g. tray, side cover and protection guard) are hinged or removable (see section "Remove/hinge down the tray and side cover").

The following applies for cleaning: The operator must ensure that the cleaning agent is environmentally friendly. Substances that are harmful to the environment, e.g. acid-forming substances, are forbidden.

Cleaning in areas with stringent hygiene requirements

SAFETY INSTRUCTIONS

When using cleaning agents, ensure they are carefully rinsed off with clear water to prevent corrosion.

Perform cleaning regularly and when required. Basically, these intervals should correspond with the cycles specified in the respective area with stringent hygiene requirements.

Procedure

- ⇒ Ensure that the unit is free of voltage.
- ⇒ Remove accessories (if any).
- ⇒ Perform cleaning tasks in acc. with the indications on the drawings (see section "Hydraulic cleaning"). Make sure to maintain the required distance and angle. An upward inclination is not permissible to protect the fan from water ingress.


- ⇒ Clean the casing by rinsing with warm water (approx. +68 °F (+20 °C) recommended) and/or with environmentally friendly cleaning agents.
- ⇒ Rinse the casing thoroughly with warm water after using cleaning agents. The unit must be free of cleaning agents to prevent corrosion.
- ⇒ Allow the casing to dry completely.
- ⇒ Fix the hinged or removable tray and the easy-to-open side covers in their original positions and secure them against unintentional or unauthorised opening.
- ⇒ Check the working fluid-side and electrical connections.
- ⇒ Clean the inside of the tray regularly.

7.4.3 Remove/hinge down the tray and side cover

Introduction

For cleaning and maintenance, the tray and the side cover can be hinged down or removed. The tray is provided with a tray securing device which has to be removed for this purpose.

Overview



Hinge the tray down (1.a)

- ⇒ Loosen and remove the top two bolts on the hinge (1)
- ⇒ Hinge the tray down (2)

Open the side panel (2.a)

- ⇒ Loosen and remove the bolts (1)

Unhinge the side panel (2.b)

- ⇒ Pull the side panel upwards and remove it (2)

7.4.4 Cleaning the coil


Introduction

Removing the fans (see section "Dismantling and disposal") creates space with a few simple turns for better cleaning of the heat exchanger coil. The cleaning method depends on the type and de-

gree of soiling and the place of installation. With loose and dry dirt, cleaning with compressed air is sufficient. With solid, damp and greasy dirt, we recommend hydraulic cleaning.

Specific hazards

⚠ CAUTION	
	RISK OF DAMAGE TO PROPERTY! If the pressure is too high, the distance is too small or the cleaning jet hits the fins at an angle, the fins can be damaged. Mechanical cleaning with hard objects (e.g. steel brushes, screwdrivers, etc.) will damage the heat exchanger. • Use a pressure of max. 435 psi (30 bar) for hydraulic cleaning and max. 116 psi (8 bar) for cleaning with compressed air! • Keep a minimum distance of 7-7/8 in (200 mm) from the fins! • Always direct the jet at right angles to the fins (max. deviation of ± 5 degrees) to prevent the fins from bending! • Do not use hard objects for cleaning!



Preparation for cleaning

- ⇒ Perform defrosting process
- ⇒ Prepare and shut off the unit in acc. with the system's operating instructions
- ⇒ Clean the coil (heat exchanger) with one of the following procedures:
 - Cleaning with compressed air (see section "Cleaning with compressed air")
 - Hydraulic cleaning (see section "Hydraulic cleaning")
 - Cleaning with brush or brush and compressed air (see section "Cleaning with brush or brush and compressed air")

7.4.4.1 Cleaning with compressed air

Procedure

- ⇒ Blast the coil with compressed air (max. 116 psi (8 bar) pressure, distance to the fins at least 7-7/8 in (200 mm); against the air flow direction) to remove dirt and impurities. Please note:
 - Preferably clean from inside to outside and from top to bottom to prevent loosened dirt from settling on areas that have already been cleaned.
- ⇒ Clean until all dirt has been removed.

7.4.4.2 Hydraulic cleaning

Procedure

- ⇒ Always remove heavier damp or greasy dirt against the air flow direction, using a high-pressure water jet (max. 435 psi (30 bar) pressure) or a steam pressure jet (max. 435 psi (30 bar) pressure). In either case, use a flat spray nozzle (distance of at least 7-7/8 in (200 mm)) and, if required, neutral cleaning agents. Always direct the jet at right angles to the fins (max. deviation of ± 5 degrees). Please note:
 - With oily and greasy deposits, add a cleaning agent to the water.
 - When applying cleaning agents, change them from time to time to prevent resistance development in germs.
 - When using chemical cleaning agents, ensure that they do not attack the surfaces of the unit. After cleaning, the unit must be rinsed with warm water so that it is free of cleaning agents.
 - Clean against the air flow direction and from top to bottom (Güntner recommendation) so that dirt is not pushed even deeper into the heat exchanger or does not move to already cleaned areas.
- ⇒ Clean until all dirt has been removed.

7.4.4.3 Cleaning with brush or brush and compressed air

Procedure

- ⇒ Remove dry dust or dirt with a brush, a hand brush and – depending on the situation – compressed air (max. 116 psi (8 bar) pressure, minimum distance of 7-7/8 in (200 mm) to the fins; against the air flow direction) or with a powerful industrial vacuum cleaner. Please note:
 - Use soft brushes (no steel brushes or similar).
 - Preferably clean from inside to outside and from top to bottom to prevent loosened dirt from settling on areas that have already been cleaned.
- ⇒ Clean until all dirt has been removed.
- ⇒ Always brush in the longitudinal direction of the fins, never across.

7.4.5 Cleaning the fans

Procedure

- ⇒ Completely disconnect the unit and secure it against accidental switching on.
- ⇒ Remove protection guard and accessories (if any).
- ⇒ Clean the fans in acc. with one of the following procedures:

- Cleaning with compressed air: Blow the fans with compressed air (pressure max. 145 psi (10 bar), distance to the fins at least 7-7/8 in (200 mm)) to remove dirt and impurities. Clean until all dirt has been removed.
 - Cleaning with brush and compressed air: Remove dry dust or dirt with a brush or a hand brush, and then with compressed air (pressure max. 145 psi (10 bar), distance to the fins at least 7-7/8 in (200 mm)) or a powerful industrial vacuum cleaner. Clean until all dirt has been removed.
- ⇒ Switch on the unit.

7.5 Procedure after all maintenance work

After completing all maintenance work, carry out the following safety measures:

- ⇒ Ensure that the switching and activation devices, the measuring and display devices and the safety devices function properly.
- ⇒ Ensure that the working fluid fittings function properly.
- ⇒ Check the labelling of the pipes and ensure that the labels/tags are visible and legible.
- ⇒ Check the fastening and the corrosion protection of the components concerned.
- ⇒ Ensure that the electrical connections (e.g. fans and, where applicable, heating rods for electric defrosting) function properly.
- ⇒ Perform a pressure test in acc. with ASHRAE standards (or national relevant) and a leak test (see operating instructions of the plant).
- ⇒ Perform an acceptance test (see section "Performing an acceptance test").
- ⇒ Perform a functional test (see the system's operating instructions).
- ⇒ Document all tests performed and their results.

8 Dismantling and disposal

8.1 Safety instructions on dismantling and disposal

Please note

SAFETY INSTRUCTIONS

Observe all basic safety instructions (see section "Basic safety instructions"), all safety instructions for transport (see section "Safety instructions for transportation and unpacking"), all safety instructions for installation (see section "Safety instructions for installation and commissioning") and all safety instructions for maintenance (see section "Safety instructions for maintenance and cleaning")!

Specific hazards

⚠ CAUTION



RISK OF INJURY CAUSED BY CORROSION!

The unit is exposed to corrosive environment for a long time. Due to the onset of corrosion, the unit loses stability and is no longer suitable for lifting by crane or industrial truck with forks and endangers bystanders.

- Defrost the unit properly and keep it free of ice.
- Check the fan unit in acc. with the maintenance schedule.
- Check all fixing bolts and fixing devices, load-bearing components, lifting elements, fixing elements and fans of the unit regularly and especially before and after lifting the unit for corrosion damage, lifting capacity and structural integrity, and replace them if necessary. In case of doubt, hire a specialised company.
- Prior to dismantling and disposal of the unit, ensure that there are no loose or slack parts on the unit.

NOTICE

RISK OF ENVIRONMENTAL DAMAGE!

Recovering or disposing of working fluid can result in working fluid or refrigerator oil emissions being released into the environment, causing pollution.

- All working fluids must be removed from the unit by suction and disposed of by an approved specialist company in the field of refrigeration.
- Ensure that no working fluid enters the groundwater.
- Operate the facility for recovering or disposing of working fluids in such a way that the risk of working fluids being released into the environment is kept as low as possible.
- Ensure that all applicable standards and guidelines are complied with.
- Observe local regulations.

NOTICE**RISK OF POLLUTION!**

If the materials are not disposed of correctly, this could result in environmental damage.

- Only dispose of materials in compliance with the waste disposal laws that are binding for the country of operation.

8.2 Dismantling the unit

Required staff

- Dismantling must be performed by at least two people (specialist staff).

Auxiliary equipment/tools

- Lifting accessories and lifting gear
- Climbing aids

Procedure

- ⇒ Completely disconnect all systems.
- ⇒ Shut down and drain the unit (see section "Shutting down the unit").
- ⇒ Make sure that there are no loose parts on the unit.
- ⇒ Follow the removal sequence:
 - Remove the accessories for defrosting (if any)
 - Remove the protection guard (if any)
 - Remove the streamer (if any)
 - Remove the fan(s)
 - Remove the tray
- ⇒ Follow the installation steps in reverse order (siehe Abschnitt "Installation of the unit").

8.3 Disposing of the unit

Introduction

At the end of its life cycle, the unit requires proper and professional disposal of the materials and substances used.

Procedure

- ⇒ Disposal must be performed by competent persons.
- ⇒ All unit components, e.g. working fluids, lubricating oil for refrigerating compressors, coil (heat exchanger), fans and optional accessories must be disposed of properly.
- ⇒ Treat used working fluid that is not intended for reuse as waste and dispose of it safely. There must be no emissions into the environment.

- ⇒ Do not use a disposable single-use container as working fluid vapour residues in the container could escape during disposal.
- ⇒ Do not overfill the working fluid container. The maximum permissible pressure of the working fluid container must not be exceeded during the entire work process.
- ⇒ Do not pour the working fluid into a fluid container that contains a different or an unknown working fluid. Do not release this other or unknown working fluid into the atmosphere but rather identify it, reclaim it or properly dispose of as specified.
- ⇒ Instruct an officially authorised facility to destroy the working fluid.
- ⇒ With evaporators: Keep used lubricating oil for refrigerating compressors that has been recovered from the unit and cannot be reclaimed in a separate, suitable container, treat it as waste and dispose of it safely.
- ⇒ All applicable laws, regulations, directives and standards must be complied with when disposing of materials and substances.

9 Spare parts

Coolers

# Fans	Coil/Tray Heater
2	U20GD11000300230
3	U20GD16400450230
4	U20GD21300600230
5	U20GD26000700230

Freezers

# Fans	Coil/Tray Heater
3	U20GD16400450230
4	U20GD21300600230
5	U20GD26000700230

Fans

Fans	VT03226U
------	----------

10 Accessories

10.1 Accessories available as a standard

- Streamer
- Cover coatings
- TXV and EEV
- Pressure transducer
- Temperature sensor
- Check valves for hot gas
- Solenoid valves
- Repair switch

10.2 Streamer

Introduction

The constantly increasing efficiency of air coolers makes it possible to use more and more compact units. This results in a correspondingly reduced air circulation. The Güntner Streamer (air flow rectifier) can be used to improve the air circulation in cold rooms.


Safety

SAFETY INSTRUCTIONS

When assembling/mounting/installing and disassembling/removing/dismantling, observe all safety instructions in the following sections:

- "Basic safety instructions"
- "Safety instructions for operation"

Overview



Features

- Significant increase in the air throw
- Significantly higher air discharge velocity
- No additional pressure drop
- Improved efficiency

