


## „Technical description software update“

### IMPORTANT: PERFORM SOFTWARE UPDATE

#### Proceed as follows:

1. Use a standard USB memory stick for the update.  
Format your USB stick: select the recognized stick in Windows Explorer and open the context menu with the right mouse button. Start formatting.
  - a. Partition FAT32
  - b. Size allocation units 8192
  - c. Label of the partition must be **NEXO\_RAUC**
  - d. Start formatting
  - e. Copy the Update-Bundle (update-bundle-guentner-image-nexo-guentner-nexo-ec-1.raucb) to the USB Stick
2. Select „Update“ in the GMMnext main menu and insert USB stick.  
The update starts automatically after some seconds. If not, remove the USB stick and plug it in again. If the update still does not start, a restart of the GMMnext is required.



3. The update is completed after the restart. Remove the USB stick from the controller before restart.

